


INSTRUCTION SHEET

L'ATELIER
de beauté

WHAT IS INCLUDED




1X AC-Plug power cord in AC
for at home use

1X DC-plug car cord in DC for
car use

2X Removable tray inserts

HOW TO START




Switch the flip to the right to turn
on the cold side of the fridge
(green light turns on)

Switch the flip to the left to turn on
the warm side of the fridge (red
light turns on)

When the switch is in the middle
means that the fridge is turned off.

OPEN / CLOSING THE FRIDGE



The door of the fridge opens
and closes the same way. Grab
the handle on the side and push
it back like you would press a
fold back clip. Do not forcefully
close the fridge by just pushing
the door in, the handle must be
pushed back prior to closing. It
should be effortless and require
no force.

CLEANING – EXTERIOR

To clean the mini fridge door
and exterior, wet a paper towel
or cloth and wipe down the mini
fridge.

CLEANING – INTERIOR

To clean the interior of the mini
fridge it is recommended to turn
off the mini fridge with the switch
at the back. When you open the
mini fridge there may be a bit of
liquid as a result of
condensation. Use a paper towel
to wipe and dry away the
liquid. Once the water is wiped
away you can switch the mini
fridge back on.

CONDENSATION

Condensation will occur as a
result of warm air entering the
fridge each time you open the
fridge. Don't be alarmed if you
see some water at the bottom of
the fridge. To avoid this it is
recommended that you wipe
down the fridge of condensation
once every 2 weeks.

Alternatively you can place a
paper towel at the bottom of the
fridge, place your products on top
and swap the paper towel out
once it's wet.

HOW TO STORE THE FRIDGE

1. The mini fridge should be stored on a stable flat hard surface and should not be covered with anything.
2. When placing the mini fridge do not store the back of the mini fridge too close to the wall, allow a gap of 4cm-5cm for ventilation to ensure that the fans don't get blocked and overheat (the bigger the gap the better).
3. Do not cover the fan of the fridge, this can cause the fan to overheat and cause a potential fire.
4. Do not cover the fridge with anything at all times.
5. Store the fridge away from direct sunlight
6. If the fridge is put on a slippery surface, put Velcro stickers on the feet of the fridge to add friction (this is just a tip and not necessary)